



## 66 Standard Computer Mount

Parts List - Parts vary depending on kit selected when ordered.

- 1 x 66 Computer Mount Kit
- 1 x Garmin / Wahoo Twist-To-Lock insert
- 2 x M4 20mm Cap Head Screw
- 1 x M4 35mm Countersunk Screw
- 1 x M4 40mm Countersunk Screw
- 2 x M3 8mm Button Head Screw

Tools required

M3 and M2 Allen key

