

# DRAG2ZERO

## SRAM Basebar Grip Assembly GRP-BB-SRAMAXS



### Tools Required:

- 2mm allen key



#### Step 1

Remove any bartap and ensure a clean basebar



#### Step 2

Remove sticky backing from VHB pad inside grip



#### Step 3

Open up grip and slip over basebar. Ensure grip is straight along the bottom.



#### Step 4

Close grip and squeeze to help sticky pad.



#### Step 5

Place SRAM AXS Wireless Blip into case



#### Step 6

Put SRAM AXS Wireless Blip carriage into grip



Step 7

Bolt grip up. Grip will be tight to bolt to ensure a secure fit. Finger tight



Step 8

Bolt grip up. Grip will be tight to bolt to ensure a secure fit. Finger tight